



彈匣卡筭 Ambidextrous Magazine Release



左側使用彈匣卡筭(壓下彈匣卡筭,彈匣即脫落)
Push the magazine release button on left side for left hand shooter.



右側使用彈匣卡筭(壓下彈匣卡筭,彈匣即脫落)
Push the magazine release button on right side for right hand shooter.


射擊選擇鈕 Ambidextrous Fire Selector



左側位置
The selector button on left side for left hand shooter.



右側位置
The selector button on right side for right hand shooter.




全自動射擊模式
Full-Auto Mode

半自動射擊模式
SEMI-Auto Mode


保險模式
Safty Mode

爆炸圖 (OPEN-BOLT)
EXPLOSION




刀疤-H


零件表



H-01 (上槍身)



H-02 (下槍身)



H-03 (槍機組)



H-04 (槍機)




H-05 (內管337)



H-06 (覆進簧)

H-07 (槍托結合座)



H-08 (射擊選擇鈕-右)

H-09 (射擊選擇鈕-左)



H-10 (槍管前段-短)




H-11 (槍管前段-長)




H-12 (防火帽)

H-14 (退彈鈕)



H-13 (槍托卡鉤組)



※海豹托套件整組販售※
Sold entire group butt stock kit